D865



IP desk phone / Corded handset


Short User Manual

English German Italian French Spanish Portuguese Greek Polish Russian Turkish

V: 11/19/2026 - 2

Getting started

(A) Unpacking and inspecting the delivery content




A-1: IP desk phone D865 | **A-2**: Handset | **A-3**: Handset cord | **A-4**: Footstand | **A-5**: Ethernet cable: 1.5 m | **A-6**: Documentation

(B) Getting to know the D865 components

The hardware components of the D865 can be summarized as follows:


- Audio devices → **B1 - B4**
- Display and indicators → **B5 - B6**
- Hard keys → **B7 - B12**



B-1: Handset earpiece
B-2: Microphone
B-3: Casing microphone
B-4: Casing speaker
B-5: Display
B-6: Call status indication
B-7: 10 SmartLabel keys (with multicolour LED)
B-8: 4 context-sensitive function keys
B-9: 12 keys (standard ITU telephone keypad)
B-10: 5 dedicated audio keys
B-11: 6 dedicated function keys
B-12: 5-way navigation key & Cancel
B-13: Handset rest tab
B-14: Hook switch sensor

© 2026 Snom Technology GmbH

(C) Interfaces and connections



Wired interfaces

C-1: USB connectivity | Expansion module D8C:[2] 2 × USB 2.0 type A ports

C-2: Power adapter:[1] coaxial power connector (socket)

C-3: Network connectivity: 2 × RJ45-8P8C (NET/PC) sockets

- Power over Ethernet (PoE), IEEE 802.3af, class 3, IEEE 802.3az[4]
- Gigabit Ethernet (GbE)

C-4: EHS adapter:[2] RJ12-6P6C socket

C-5: Corded handset: RJ9-4P4C socket

C-6: Headset:[2] RJ9-4P4C socket

Wireless interfaces

- Third party headset support: Bluetooth
- Network connectivity: WiFi

[1] If PoE is not available
[2] Not included in delivery
[3] Optional
[4] Optional via software


© 2026 Snom Technology GmbH

Preparing the D865 for use


Attaching footstand and handset

1. Before attaching the footstand to the phone, plug the long end of the handset cord into the RJ9-4P4C connector labelled  on the back of the phone and place the cord in the cable guide.
2. Place the top of the grooves on the footstand below the slideguides on the back of the D865.
3. Push the footstand upwards onto the slideguides until it locks into place.
4. Plug the short end of the handset cord into the connector on the handset.
5. Place the D865 on an even, horizontal surface.


1



2



3



Connecting and powering up

The phone can be operated with Power over Ethernet (PoE) provided via the network cable or, if PoE is not avaible in your network, with the separately available 5V DC power adapter

1. Plug one end of the Ethernet (network) cable into the RJ45 connector labeled **NET** and the other one into the network side to establish a data link.
2. If PoE is not available, hook up the plug of the power supply to the wall outlet.
3. The second RJ45 connector, labeled **PC**, is for daisy-chaining further Ethernet devices without the need for a second Ethernet connection line.
4. Snom phones are plug-and-play. Once the phone is connected to your network, it will begin to initialize. If your local network or VoIP provider supports *Snom's auto provisioning features*, the phone will start up automatically without interruption. In this case continue with the next chapter, otherwise refer to chapter ***Putting the D865 into operation***


© 2026 Snom Technology GmbH

Getting to know the display and controls


Display (see → *Getting started → Getting to know the D865 components* → B-3)

This display presents the following information:

In idle mode:




1. **Info bar/status line**
   1. Outgoing SIP identity **(see → *Navigation, confirmation, and cancel keys*)**
   2. Time | Audio devices | Info (Bluetooth, VPN...)
2. **Context area**
   1. 10 × SmartLabel **(see → *SmartLabel keys*)**
   2. Date and time
   3. 7 × Favicons → shortcuts to menus **(see → *Navigation, confirmation, and cancel keys*)**



3. **Function key line, context-sensitive, see → Context-sensitive, programmable function symbols and function keys**

When the phone is active:



1. **Info bar/status line**
   1. Name of current activity | Outgoing SIP identity
   2. Audio devices | Info (Bluetooth, VPN...) | Time
2. **Context area**
   1. 10 × SmartLabel: Depending on the context, the SmartLabels will or not be shown.
   2. Depending on the activity, this area will contain symbols (incoming call ringing, outgoing call ringing, list entries, etc.) and text like the phone number calling, the extension number being called, conference partners, etc.
3. **Function key line, context-sensitive**
   Depending on the current activity of the phone, the function key line will present various functions that can be activated by pressing the function key underneath the respective symbol.

© 2026 Snom Technology GmbH


Call indicator (see → *Getting started → Getting to know the D865 components* → B-4)

The bright-red LED situated on the top right corner of the phone indicates **incoming, ongoing, held, and missed calls**. LED status indications:

- Blinking rapidly when a call is coming in.
- Glowing steadily when dialing, when in a call, and when you have missed a call. To turn the LED off after a missed call, press the right arrow on the navigation key to view the **Missed calls** menu and simultaneously turn off the LED.
- Blinking slowly when you have put a call on hold.

SmartLabel keys (see → *Getting started → Getting to know the D865 components* → B-5)

10 SmartLabel keys (freely programmable function keys with LEDs) on the both sides of the display control the SmartLabels. They can be programmed and labeled on the phone via menu-driven phone user interface (PUI) and on the **Function Keys** page of the phone's web user interface **(Phone Manager)**.



Each of the **10** physical keys can be assigned to different functions on **4 SmartLabel pages**, which finally gives a total number of **40** SmartLabel keys.

You can switch between the SmartLabel pages using the following key:



Next page

Default setting:


- Page **1**: **P1-P3** → Line, **P4 + P5** → Unassigned, **P6** → Do Not Disturb (DND) mode, **P7** → Missed calls, **P8** → Redial → List dialled calls, **P9** → Voicemail Info, **P10** → Next page
- Page **2**: **P11-P19** → Unassigned, **P20** → Next page
- Page **3**: **P21-P29** → Unassigned, **P30** → Next page
- Page **4**: **P31-P39** → Unassigned, **P40** → Next page

Depending on the function mapped onto the key, the red or green LEDs on the key will be activated when the key event occurs. The LED of a **line** key will

- blink rapidly when a call is ringing on the line
- glow steadily when there is an ongoing call on the line
- blink slowly when a call is on hold on the line
- be off when the line is free.


© 2026 Snom Technology GmbH

Depending on the key type, label areas are composed of icon and text, or only text respectively. Both can also be customised. The following **key types** are available with current firmware:



Key types: Unassigned


Line


Do Not Disturb


Forward all


Call history


Speed Dial


Directory


Settings


Busy Lamp Field


Private Hold


Dialled calls


Voicemail


Transfer


Next page


Conference


Extension


Call Parking


Hold


Status


Missed Calls


Received calls


Redial


Server Directory


XML Definition



Automatic Call Distribution


Action URL


Multicast


Multicast Zones


Voicemail Info


SIP identities


Intercom

© 2026 Snom Technology GmbH


Context-sensitive, programmable function symbols and function keys (see → *Getting started → Getting to know the D865 components* → B-6)

4 context-sensitive, programmable function keys (F1 - F4) are located directly below the display and can be programmed on the **Function Keys** page of the phone's web interface **(Phone Manager)** with a number of key events; these functions will then be available when the phone is in idle mode. Default settings depend on the firmware installed on the phone.

Standard functions available on idle screen:

- **F1**: Settings → Settings menu
- **F2**: Call History → Call lists (missed, received, dialled calls)
- **F3**: Notifications or Info → Status information
- **F4**: Directory → Accessing the built-in directory of the phone

Press the function key underneath the display symbol to activate the function, open the list etc. depicted by the symbol above the key.



Alphanumeric keypad (see → *Getting started → Getting to know the D865 components* → B-7)


1 alphanumeric keypad consisting of 12 hard keys, located in the center of the lower device part.

- **In editing mode:** Press **(1)** for one second to change input mode (numerals > lower case > upper case) or press **(1)** briefly to type *.
- **On idle screen:** Press **(1)** for 3 seconds to lock/unlock the keypad.



© 2026 Snom Technology GmbH

Audio control keys (see → *Getting started → Getting to know the D865 components* → B-8)



5 audio control keys are used to adjust the volume, for muting and unmuting the microphone, to activate speakerphone and headset mode.

1 2 Volume + / -

- **Adjusting the volume of the ringer when the phone is idle or ringing**
- Adjusting the volume of the loudspeaker in handset, casing, or headset, respectively, when in call

3 Mute

- **Muting and unmuting the microphone**
- Lights up red when and as long as the microphone is muted.


4 Speakerphone

- **Toggling between handsfree and handset mode**
- Dialling and accepting calls on speakerphone
- Lights up green when and as long as the mode is activated.

5 Headset

- Toggling headset mode on and off

Dedicated, customizable function keys (see → *Getting started → Getting to know the D865 components* → B-9)



6 preprogrammed, variably programmable function keys have their factory settings printed on the key. Other functionalities can also be programmed onto them.

1 Message

- **Retrieving messages from the mailbox (if applicable)**
- Lights up red when there is a new message on the mailbox.

2 Conference

- Initiating a conference

5 Redial

- Redial (via dialled calls list)

3 Directory

- Accessing the built-in directory of the phone

6 Hold


- **Holding or unholding an active call**

4 Transfer

- see → *Using the phone → (5) Transferring calls*

© 2026 Snom Technology GmbH

Navigation, confirmation, and cancel keys (see → *Getting started → Getting to know the D865 components* → B-10)



They can be programmed with the key events available in their drop-down menus.

You can select a different key event to be available on each respective key when the phone is in idle mode. You cannot change the functions that are available when the phone is active, for example when you are in a call, when the phone is ringing, etc.

Default setting:


1



Confirm

- **On idle screen:** call features menu
- Accepting calls on speakerphone and in headset mode
- Confirming, saving actions & input, and returning to previous screen

2
3



Navigation key: up/down

- **On idle screen:** Select the outgoing identity



- In other contexts: Navigate up/down

4



Navigation key: left

- **On idle screen:** Select a favicon (shortcuts to menus)



Preferences DND System Bluetooth WiFi Voicemail Call Features


5



Navigation key: right

- **In editing mode:** Moving the cursor to the right one character at a time or Moving the cursor to the left one character at a time

6



Cancel


- Terminating calls on speakerphone and in headset & handset modes
- Canceling actions & input, and returning to previous screen

© 2026 Snom Technology GmbH


Putting the D865 into operation

(1) Initializing and registering the phone

1 → When the phone has been connected, it will show the welcome screen with the IP address of the **Phone Manager**. It is more convenient and therefore recommended to perform the first time setup using the **Phone Manager**. Enter the *IP address* into the web browser's address bar on a computer in the same network as the D865.




2 → The page **Snom Phone Manager** opens.




Click on **Authenticate (button label)**. → The page **Welcome to the Phone Manager** opens **(page title)**

3 → Click on **Start First Time Setup (button label)**.




4 → The page **Language** opens **(page title)**.



You will be prompted to select a **language**:


1. **Web user interface (WUI)**
2. **Phone user interface (PUI)**
3. When done, click **Apply**.

5 → The page **Time & Date** opens **(dialog title)**.



1. Next, you will be prompted in the language of your choice to select a **time zone**. This affects the time shown on your display.
2. When done, click **Apply**.


6 → The page **Account Credentials** opens **(dialog title)**.




© 2026 Snom Technology GmbH

7 → Enter an **admin username and password** for accessing the phone's web user interface (Phone Manager).

1. The suggested user name can be used or a new one can be entered.
2. You are obliged to set a proper **admin password** to operate the phone.
3. Re-enter the password for confirmation.
4. When done, click **Apply**.




The page **Your device is ready** opens **(dialog title)**.




The phone is now ready to set up the first SIP identity (account) to be fully operational.

8 → Click on **Configure SIP Identity (button label)**. → The page **Homepage / Identities / 1 / Profile** opens **(page title sub page / 1 / sub page)**.

9 → Enter the **(1) Account**, the **(2) Password**, and the **(3) Registrar** received from your Internet service provider or administrator. When done, click **Apply**.



After successful registration you will see the **idle screen** with the registered identity in the upper left corner.



© 2026 Snom Technology GmbH

Adjusting the D865 settings

A comparatively small number of settings can be adjusted directly **on the phone** via *menu-driven phone user interface (PUI)*; many more can be conveniently customized via the *phone's web user interface (Phone Manager)* from a **computer with web browser**.

Note: Snom phones can be operated in administrator or user mode. In administrator mode, all settings are accessible and can be modified; in user mode, a number of settings are not accessible. → **Default setting**: administrator mode

Phone user interface (PUI)

On idle screen:
Press



Settings

to open the settings menu on the display. To open submenus and settings, select the submenu or setting with the navigation key and press



Confirm

Web user interface (WUI) / Phone Manager


1. Press the function key underneath **Settings** on the phone's display and select **Help** to look up the phone's IP address.




Settings

2. Enter the *IP address* into the web browser's address bar on a computer in the same network as the D865. The page **Welcome to the Phone Manager** opens **(page title)**.
3. Log into the Phone Manager using the correct credentials. The page **Home** opens


1



2



3



Available items in the vertical menu on the left side of the window depend on whether the phone is running in user or administrator mode. Any changes you make on the web interface will not take effect until you click on **Save** or on **Apply** and **Save**, depending on your firmware version. Changes will be lost if you open another page of the web interface without first clicking on **Apply/Save**.

© 2026 Snom Technology GmbH

Using the phone

This section describes the functions of the phone with the factory default settings. If your phone was installed and/or set up by someone else, the default settings may have been changed. Please check with that person or company if the phone does not react as described here.

Note: The caller information displayed on the screen is controlled by a setting on the phone's web interface. The default setting is *Name + Number*.

Making calls

1. **On idle screen:** Select the outgoing identity
2. Using different **audio devices**
   - Handset: Pick up the handset, enter the phone number, and confirm with



Confirm

or



Dial

or enter the phone number and pick up the handset.



   - Headset: Enter the phone number and press



Headset

   - Speakerphone: Enter the phone number and press



Speakerphone

or



Dial

Accepting calls

- Handset: Pick up the handset.
- Headset: Press



Headset

If the phone is already in headset mode, you can also press the blinking line key.

- Speakerphone: Press



Speakerphone


or



Answer

Terminating calls

- Handset: Place the handset in the cradle or press
- Headset or Speakerphone: Press



Cancel

or



End call

© 2026 Snom Technology GmbH

Active calls

One call on hold

Press



Hold

or



Hold

to put the ongoing call on hold. Held calls are indicated as follows:

- By the text on the display.
- By the slowly blinking line key.
- By the slowly blinking call indication LED.
- By the double beep when you put a call on hold.

You can now:

- transfer the held call blindly or with prior announcement.
- receive and make calls and put other calls on hold.

Pick up the held call by pressing its line key or press again



Hold

or




Resume


If the other party hangs up while on hold, the call is terminated on your phone as well and the LED indicators are turned off.

Holding multiple calls


Display → Context area:




Two calls, one active, one on hold.



Two calls, both on hold.




Press



Navigation key: up/down

to scroll through the calls.



You can now:

- switch back and forth between the active call and any call on hold. Up to 12 simultaneous calls are possible, if supported by the VoIP telephony system.
- Your input on the phone's keys will affect the call on the display. It can be resumed, terminated, or selected for conference setup.
- When a held call is on-screen, press



Hold

or



Resume


to connect to it and put the currently connected call on hold.

© 2026 Snom Technology GmbH

Conference


The maximum number of participants in phone-based conferences is **5** (you and 4 others). For the number of participants in server-based conferences and how to set up and join them, please check with your network administrator or your VoIP provider.

1. With an active call **(B, 101)** on the line, press




Conference

1




2.1



2. The call **(B, 101)** is put on hold. The page **Conf setup** opens **(page title)**. Enter the number or select a call from the phone's call list. Call the next intended participant **(C, 102)** and announce the conference.


3. Press




Join

to start the 3-way conference

2.2



3



You can now:


- Put the conference on hold.
  Press



or




Hold Hold




- Press



or



Hold Resume



to restart the conference.

- Press




or



to terminate the conference.


Cancel End call

- Press



Details


The page **Details** opens



© 2026 Snom Technology GmbH

Use the navigation key to select individual participants or the conference. Your input on the phone's keys will affect the highlighted participant or the entire conference.

- You can end or split the highlighted conference.
- You can mute or remove the highlighted individual participant.





Press



Bridge


to terminate the conference. You leave the conference, the two external participants **(B, 101)** and **(C, 102)** continue talking.

Press



Split

to terminate the conference. → Two calls, both on hold.



Press



Mute

or



Unmute

to mute/unmute the selected call **(C, 102)** during the conference.




Press



Remove

to remove the selected call **(C, 102)** from the conference. This will also terminate the conference. → 1 active call (B, 101)



© 2026 Snom Technology GmbH

Transferring calls

You can transfer connected calls as well as deflect calls ringing on your phone.

- When you have a call on the line, there are two ways to transfer it to a third party
  1. Attended call transfer: Announcing the call to the third party first, to make sure the call is welcome and will be accepted.
  2. Blind call transfer: Transfer the call without any feedback on whether the third party is available and/or picking up the call.
- Call deflection: When a call is ringing on your phone, you can redirect it to a third party without answering it first.

Attended call transfer: with a single call on the phone

1. With an active call **(B, 101)** on the line, press




Transfer

or



Transfer

1.1



1.2



The call **(B, 101)** is put on hold. The page **Xfer setup** opens **(page title)**.

2. Enter the number or select a call from the phone's call list. Press



Dial

or



Confirm


Dial the number **(C, 102)** you want to transfer the call **(B, 101)** to and announce the call.

Note: If the third party does not want to take the call




End call

2



3. If the third party **C (102)** wants to accept the call: Press




Transfer

to complete the transfer.

Note: The completed call transfer is indicated by the brief appearance of the screen message **Call ended (Call ended B 101)**

→ **B (101)** is now in a call with **C (102)**.

3




© 2026 Snom Technology GmbH


Attended call transfer: with more than one call → **B, 101 + D, 103**

1. The active call **(B, 101)** will be transferred. If the active call **(B, 101)** is not the one you want to transfer, put it on hold and select the other call **(D, 103)**.

1.1



1.2



2. Press



or



Transfer Transfer

→ The call **(B, 201)** is put on hold. The page **Xfer setup** opens **(page title)**.

2



3. Enter the number or select a call from the phone's call list. Press



or



Dial Confirm


Dial the number **(C, 102)** and announce the conference.

Note: If the third party does not want to take the call: Press



End call

3



4. If the third party **C (102)** wants to accept the call: Press




Transfer

to complete the transfer.

→ **B (101)** is now in a call with **C (102)**.

→ The remaining call on hold or the first of the remaining calls on hold will then appear on-screen **(D, 103)**.

4



© 2026 Snom Technology GmbH

Blind call transfer: active call **(B, 101)**

1. With an active call **(B, 101)** on the line, press




Transfer

or



Transfer

1



2.1



→ The call **(B, 101)** is put on hold. The page **Xfer setup** opens **(page title)**.

2. Enter the number manually or select a number from the phone's call lists. Press




Blind call transfer

to complete the transfer.

Note The completed call transfer is indicated by the brief appearance of the screen message **Call ended (Call ended B 101)**.

→ **B (101)** is now calling **C (102)**.

2.2



Call deflection: (call waiting **C 102**)


1. If you are in an active call **(B, 101)** and want to deflect an incoming call waiting **(C, 102)**, press



Navigation key: up/down

→ The incoming call waiting appears on-screen.
→ Your active call remains active while you are transferring the ringing call.

1



2. Press



Transfer


or



Forward

→ The page **Forward call** opens **(page title)**.

2



3. Enter the number manually or select a number from the phone's call lists. Press




Forward

to complete the deflection.

→ **C (102)** is now calling **D (103)**.
→ Your active call **(B, 101)** reappears on-screen.

3



© 2026 Snom Technology GmbH

Call deflection: (ringing call **B 101**)

1. With an incoming call ringing **(B, 101)**, press



Transfer


or



Forward

→ The page **Forward call** opens **(page title)**.

1



2. Enter the number manually or select a number from the phone's call lists. Press




Forward

to complete the deflection.

→ **B (101)** is now calling **C (102)**.


2



Call lists

Four call lists of missed, dialed, received, and all calls are stored on the phone.

1. **On idle screen:** press the function key underneath the following symbol




Call history

2. To display the lists of missed, received, or dialed calls on-screen, use the navigation key (left/right). On each list, the latest call is at the top of the list. Scroll through the list using the navigation key (up/down). The icons indicate the type of call.



Navigation key

1



© 2026 Snom Technology GmbH

Software update


Manual update

1. Visit Snom's Firmware Update Center and find the latest firmware version for your D865.
2. Please read the instructions and release notes before downloading the firmware.
3. **Right-click** the *download link* in the Firmware files table and **copy the link**.
4. Open the phone's web user interface **(Phone Manager)**. Navigate to page *Software Update (...)*. In the *Manual Software Update* area, paste the link into the text field of **Firmware**.
5. Click **Load**. The phone begins to reboot.
6. **Note: DO NOT DISCONNECT THE POWER WHILE THE D865 IS REBOOTING!**

3




4



Auto provisioning

1. Open the **Phone Manager** and click **Maintenance**.
2. Click **Provisioning**.
3. Click the individual settings for their details.
4. When done, click **Apply**. If you have the changed the setting URL and/or the *PnP configuration*, a reboot is required before they will take effect.



For more information, see our **web page.**

© 2026 Snom Technology GmbH

Troubleshooting

Contacting Snom Support

Click this text (or scan the QR code) to read and follow the detailed instructions given on our website.

Submitting a ticket

Click this text (or scan the QR code) to read and follow the detailed instructions given on our website.

Submitting system and settings information

- **System information**
- **Settings information**

SIP/PCAP traces

Our support team may ask you to submit a SIP Trace and/or a PCAP Trace to help them analyze your problem.

- **Performing a SIP trace**
- **Performing a PCAP trace**

Important information

This **D865 Short User Manual** has been derived from the more extensive user manual to give users a more concise overview in their own language.

Disclaimer

Further information: D865 webpage | **Snom Service Hub D865** | **Data sheet D865** | **User manual D865** | **General Public License (GNU)** | **Warranty information** | **Type approval** | **Company locations**

Snom, the names of Snom products, and Snom logos are trademarks owned by Snom Technology GmbH. All product specifications are subject to change without notification. Snom Technology GmbH reserves the right to revise and change this document at any time, without being obliged to announce such revisions or changes beforehand or after the fact. Although due care has been taken in the compilation and presentation of the information in this document, the data upon which it is based may have changed in the meantime. Snom therefore disclaims all warranties and liability for the accurateness, completeness, and currentness of the information published, except in the case of intention or gross negligence on the part of Snom or where liability arises due to binding legal provisions.

© 2026 Snom Technology GmbH